



In the Box

Check that all of the following items are in your package. If any items are missing, please contact DJI^{TM} or your local dealer.

Aircraft ×1 (Intelligent Flight Battery and Gimbal Cover included) Remote Controller ×1





Charger ×1



Power Cable ×1



Propeller Pair ×3



Gimbal Clamp ×1



microSD[™] Card ×1 (16 GB)



Micro USB Cable ×1



RC Cable







RC Cable Slider





Manuals



- · MAVIC PRO In the Box
- · MAVIC PRO Quick Start Guide
- MAVIC PRO Disclaimer and Safety Guidelines
- · MAVIC PRO Intelligent Flight Battery Safety Guidelines